



Indoor Solar Development Kit with TI BLE Quick Start Guide

Required Materials: Indoor Solar Development Kit with TI BLE / Android Device / Small Flathead Screwdriver


Step 1: Connect the rechargeable Li-Polymer battery to the circuit board.



Step 2: Connect the LL200-2.4-75 solar panel to the circuit board.



Step 3: Install the PFDEV-TI Data Monitor on your Android device from the Google Play Store.



Step 4: Use the Data Monitor to scan and connect to the development kit.



Step 5: View live temperature, light level and battery level data from the development kit. Adjust and test connection and sensor settings as desired.

See manual for more detailed instructions